



SmartPTT PLUS

Installation & Configuration Guide

Version 8.7

June, 2015



Table of Contents

1.1 Introduction	2
1.2 SmartPTT Software Installation	2
1.3 General SmartPTT Radioserver Configuration	5
1.4 SmartPTT Dispatcher Configuration	8
1.5 Connect Plus	14
1.5.1 MOTOTRBO Equipment Programming	15
MOTOTRBO XRC Controller and XRT Gateway	16
MOTOTRBO Radio Programming	19
1.5.2 SmartPTT Radioserver Configuration	20
1.6 Linked Capacity Plus	26
1.6.1 MOTOTRBO Equipment Programming	27
MOTOTRBO Repeater Programming	28
MOTOTRBO Radio Programming	38
1.6.2 SmartPTT Radioserver Configuration	46
1.6.3 MNIS and DDMS Client Configuration	51

Installation & Configuration Guide

1.1 Introduction


Installation and configuration of the SmartPTT PLUS system is a complex task and comprises the following steps:

1. Installation and configuration of SmartPTT Radioserver.
2. SmartPTT Dispatcher installation and configuration.
3. Configuration of MOTOTRBO devices, e.g., radios and repeaters.
4. Configuration of MOTOTRBO tools: MOTOTRBO Network Interface Service Configuration Utility and MOTOTRBO DDMS Administrative Client (for networks based on the NAI protocol).


The system configuration depends on the network used and the devices available. In this document, you will learn how to install and configure the system on the basis of Linked Capacity Plus (LCP) and Connect Plus networks consisting of 3 sites.

1.2 SmartPTT Software Installation


1. After downloading SmartPTT PLUS distribution kit, unpack it to a separate folder.



2. Run **autorun.exe**.




3. Install SmartPTT Radioserver first and then SmartPTT Dispatcher. For both installation processes the setup wizard will be used.




4. Follow the steps of the setup wizard.

Note: When installing SmartPTT Radioserver, please remember that Microsoft SQL Server is used by SmartPTT Radioserver to log network events. This feature is optional and turned off by default.



Note: When installing SmartPTT Dispatcher, make sure you have SQL Server installed. If not, install SQL Express together with the dispatcher console.




5. Once you have finished, close the installation window.

1.3 General SmartPTT Radioserver Configuration

General configuration includes parameters that are independent of the network type. To configure the general settings of the radioserver open SmartPTT Radioserver Configurator.


1. Set up parameters of the radioserver.




- In the **Name** field specify the radioserver name. This name is used only in SmartPTT Radioserver Configurator;
- In the **Interface** field and the **Port** field specify the IP address and port of the PC where the radioserver is installed.

2. Enable radio network services, e.g., ARS, GPS and TMS support.


- To enable ARS support, select the **Active** check box under **ARS**:



- To enable GPS support, select the **Active** check box under **GPS**:



- To enable text messaging service, select the **Active** check box under **TMS**:



1.4 SmartPTT Dispatcher Configuration

In this topic you will learn how to configure general settings of the SmartPTT Dispatcher console. The general configuration in the scope of the LCP or Connect Plus network implies that operators will be able to communicate with radio subscribers and the radio subscribers will be able to communicate with each other.

The general configuration of the SmartPTT Dispatcher console includes the following steps:


1. License installation
2. Database creation
3. Radioserver configuration
4. Audio setting configuration
5. Registration of radio subscribers

The description of the steps is given below:

1. Expand the **Settings** menu in the **Main Menu** bar of the SmartPTT Dispatcher window and click **Licenses**.

Install the required license, which includes:

- SmartPTT PLUS license
- Additional Radioserver license
- Subscriber license, which allows you to register radio subscribers




After uploading the license, click **Finish** to apply.

2. Expand the **Settings** menu in the **Main Menu** bar of the SmartPTT Dispatcher window and click **Database**. In the opened window create the new database and then connect to it.

To create a new database, fill in the **Database Server Name** and click **Create New Database**. For a database server installed together with the SmartPTT dispatcher application enter the name using the format: Name of PC \SQLEXPRESS (for example, MYCOMP\SQLEXPRESS).

In the window that opened enter the name of the new database and click **Save**.



If creation was successful, a message about successful database creation is displayed. If the database is not created, the reason will be displayed at the bottom of the window.

Authorization Mode – allows you to select authorization mode with the database.


SQL Server Authorization – you must have the login and password of the account which has access to the SQL server.

Windows NT Authorization – the user who has logged into the Windows system, must be listed in the SQL server's list of users to make connection.


After you have finished, click **Finish** to save the changes. You will need to restart SmartPTT Dispatcher to apply

the changes.

3. In the **Settings** menu click **Radioservers** to add the radioserver and configure it properly.



Click **Add** to open the window for adding radioservers to the list.




Enter the name of the radioserver in the **Name** field. The name will be displayed in the SmartPTT Dispatcher console.

In the **Address** and **Port** fields enter the radioserver IP address and port number to connect with the dispatcher. To find out the radioserver IP run the *ipconfig* command on the PC where the radioserver is installed. The default radioserver port number is *8888*.

Select the **Active** check box to enable the radioserver.

For more information about the radioserver settings see Help in the SmartPTT Dispatcher application.

4. Audio setting configuration is required to give the operator the ability to communicate with the radio subscribers. Expand the **Settings** menu in the **Main Menu** bar of the SmartPTT Dispatcher window and click **Sound**.



The screenshot shows the 'Configuration' window with the 'Sound Settings' tab selected. The window title is 'Configuration' and it features the SmartPTT logo. The 'Sound Settings' section is titled 'Audio devices and VoIP settings'. It contains three main sections: 'General Settings', 'Audio Output Devices', and 'Other Settings'. The 'Audio Input' section includes a 'Device' dropdown set to 'Microphone (2- USB audio CODEC)', an 'Input Line' dropdown set to 'Audio', and a 'Noise Reduction' dropdown set to 'Disabled'. Below these are 'Record', 'Check', and 'Save' buttons. The 'Audio Output' section has a 'Device' dropdown set to 'Default' and a 'Check' button. The 'VoIP Parameters' section includes a 'Codec' dropdown set to 'CCITT u-Law', a 'Codec Format' dropdown set to '8000 Hz, 20 ms, 64 (86) kbps', and a 'VoIP Port' text box containing '18501'. At the bottom of the window are 'Help', 'Cancel', and 'Finish' buttons.

Audio Input – audio device to which the microphone is connected.

Input Line – audio mixer line used to connect a microphone.

Audio Output – audio device to which headsets or speakers are connected.

Codec – audio stream compression method.

Bitrate – audio stream sampling frequency.

VoIP Port – audio stream receive port.

Specifications of the codec format *8000 Hz, 20 ms, 64 (89) kbps*:

8000Hz – the sampling rate.


20 ms – the frame size.

64 kbps – the voice data bit rate.

89 kbps – a full bit rate (required network bandwidth).

For more information see Help in the SmartPTT Dispatcher application.

5. Register radio subscribers. Unregistered radio subscribers are displayed in italics in the **Radio Fleet** window and are not recorded into the database.



To register the radio subscriber, right-click on the radio subscriber, enter the name and click **Save**.

The screenshot shows a dialog box titled "Properties: Mike" with a close button (X) in the top right corner. The dialog has three tabs: "General", "Location", and "Custom". The "General" tab is selected. On the left side of the "General" tab, there is a small image of a person wearing a hard hat and holding a radio. Below the image are two buttons: "Select" and "x". To the right of the image, there are several input fields and controls: an "IP" field containing "12.0.0.22", an "MDC ID" field, a "5 Tone ID" field, a "Name" field containing "Mike", and a "Status" dropdown menu showing "(empty)". Below these fields are three icons: a USB symbol, a printer symbol, and a person with a radio symbol. At the bottom left of the dialog, there is a checked checkbox labeled "Lone Worker" and a "Security" dropdown menu. At the bottom center, there are two buttons: "Save" and "Cancel".

1.5 Connect Plus

SmartPTT PLUS supports Connect Plus multi-site trunking system, which starting from version 8.5 can be used not only for ARS (i.e., Presence Notification service), TMS and GPS functionality, but also for voice communication between the dispatcher and radio subscribers.

Connect Plus network can include up to 15 repeaters (29 channels + 1 control channel) on each site. Each site must have at least one XRC Controller. It is the core of the Connect Plus network and its presence on each site is obligatory. The XRC Controller provides central call processing and real-time resource management for MOTOTRBO Connect Plus digital trunking systems. There can be two XRC Controllers per site if one of them serves as backup to the primary XRC. The secondary controller provides backup capability, but it does not increase the number of repeaters and calls that can be managed per site.

XRT Gateways are required for voice communication and call event monitoring.

Note: You can also use control stations for this purpose, in case you do not have the XRT Gateway. For more information on how to use control stations instead of the XRT Gateway for voice communication see the help file of SmartPTT Radioserver Configurator.

MOTOTRBO Connect Plus multi-site trunking network provides extended load capacity and provides digital communication to as many as 2,900 users per site.

For more information about the XRC Controller and XRT Gateway see MOTOTRBO Connect Plus System Planner.

The Connect Plus network configuration includes the following stages:

1. Setting up MOTOTRBO equipment configuration parameters: XRT Gateway, XRC Controllers, repeaters, radios.
2. Setting up SmartPTT Radioserver parameters to operate with Connect Plus network.

The goal of this document is to help system administrators configure SmartPTT Radioserver parameters to operate in the Connect Plus network. Therefore, the document contains detailed information on SmartPTT Radioserver settings, specific to this network type, XRC Controller and XRT Gateway settings that are necessary for the operation with SmartPTT Radioserver, and some settings of MOTOTRBO radios, which we think must be covered. For detailed description of MOTOTRBO equipment settings see MOTOTRBO Connect Plus System Planner.

1.5.1 MOTOTRBO Equipment Programming


To program MOTOTRBO equipment you will need special MOTOTRBO configuraton software:

- MOTOTRBO Customer Programming Software (CPS);
- MOTOTRBO Connect Plus XRC Network Manager for XRC Controller configuration;
- MOTOTRBO Connect Plus XRT Network Manager for XRT Gateway configuration;
- MOTOTRBO Connect Plus Option Board CPS for radio option board configuration

Note: Make sure you that firmware versions for all MOTOTRBO equipment used in one network are compatible.

MOTOTRBO XRC Controller and XRT Gateway

The scheme below shows the sample Connect Plus network.



In this network there is only one XRT Gateway in the network system, and one XRC Controller per site. The number of repeaters per site can be different. In this case there are two and three repeaters on site.

The XRT Gateway joins the MOTOTRBO Connect Plus system as another multi-site XRC Controller peer. It creates a pathway between the radios on a Connect Plus system and the third party application, in our case it is SmartPTT Radioserver.

The XRC Controller controls up to 15 MOTOTRBO repeaters per trunked site. Because this is an IP interface, the XRC Controller and its connected repeaters could theoretically be in different locations. However, due to the time sensitive nature of the messaging between the controller and the repeaters, the XRC Controller and its trunked

repeaters must be at the same physical location and connected to the same Ethernet switch. The XRC Controller can control up to 30 digital channels (timeslots) per Connect Plus site. One of these timeslots must be dedicated for Control Channel signaling. All other timeslots are used by the controller for call assignment.

In this article we will focus mainly on the most critical parameters of the XRC Controller and XRT Gateway, which are required for operation with SmartPTT Radioserver. Other information on the XRC Controller configuration can be found in MOTOTRBO Connect Plus System Planner.

1. In our example we have a multisite networking, therefore each XRC Controller must be enabled for multisite operation.
2. Make sure the **Pool IDs** field in SmartPTT Radioserver Configurator matches the **Pool ID** field in XRT Gateway settings.

The screenshot displays the configuration interface for the XRT Gateway and Site Configuration. The XRT Gateway configuration is shown in the center, with the Pool IDs field highlighted in red. The Site Configuration panel is shown on the right, with the Pool ID field in the Pool ID Configuration section also highlighted in red. A red arrow points from the Pool IDs field in the XRT Gateway configuration to the Pool ID field in the Site Configuration panel.

XRT Gateway Configuration:

- Active:
- Name: XRT
- Gateway Address:Port: 192.168.7.122:10001
- Pool IDs: 16000001-16000010
- Username: username1
- Password: password1
- TX Time-Out Timer, sec: 60
- Group Call Hang Time, ms: 4000
- Private Call Hang Time, ms: 6000
- Emergency Call Hang Time, ms: 8000

Site Configuration:

WARNING: Changes to this section will require a reboot of XRT 9000.

Site Configuration:

- Local Site ID: 255
- Connect Plus Network ID: 298

Network Configuration:

- Multisite UDP Start Port: 46000
- Max Multisite Ports: 32
- Multisite Ping Int.: 2500 ms.
- Multisite Control Port: 45000
- Client TCP Port: 10001
- Client UDP Start Port: 7700

NTP Configuration:

- NTP Server
- NTP Server Address: [Empty]
- NTP Update Interval: 60000 ms.

Pool ID Configuration:

- Pool ID: 16000001-16000010

3. Make sure that there is a user record for every pool ID in XRC Controller configuration:

Record Type	ID	Alias	Priority	Status	Serial Number	Multigroup ID	Notes
User	101	Disp 101	8	Enabled	037TMLV000	1000	
User	102	Disp 102	8	Enabled	037TMLV001	1000	
User	201	201	8	Enabled	037TMLV348	1000	
User	202	202	8	Enabled	037TMLV343	1000	
User	403	403	8	Enabled	037TMT1829	1000	
User	16000001	XRTClient	8	Enabled		1000	
User	16000002	XRTClient	8	Enabled		1000	
User	16000003	XRTClient	8	Enabled		1000	
User	16000004	XRTClient	8	Enabled		1000	
User	16000005	XRTClient	8	Enabled		1000	
User	16000006	XRTClient	8	Enabled		1000	
User	16000007	XRTClient	8	Enabled		1000	
User	16000008	XRTClient	8	Enabled		1000	
User	16000009	XRTClient	8	Enabled		1000	
User	16000010	XRTClient	8	Enabled		1000	
Group	1001	Group 1	8	Enabled			
Group	1002	Group 2	8	Enabled			
Group	1003	Group 3	8	Enabled			
Multigroup	1000	1000	8	Enabled			

4. Check user restrictions under **XRT User Configurations** in MOTOTRBO Connect Plus XRT Configuration Tool:

Username	Max Talk Paths	Billing Enabled	NWAC Enabled	Data Path R...	Group Talk Paths	Private Talk Paths
xrttestuser	10	False	True	False	1000-1003	101

- Check that the **Username** and **Password** match **Username** and **Password** in SmartPTT Radioserver Configurator in XRT Gateway settings.


- Check the **Group ID**. The values in the field must match the IDs used for group calls in SmartPTT Radioserver Configurator in XRT Gateway talk path settings. If the field is empty, the user should have permission for any Group Talk Path that it validly registers with the XRT 9000. If any Group ID is entered, then all Group IDs not configured into this field will be disallowed!
- Check **Console User ID**. It should match **Radio ID** in SmartPTT Radioserver Configurator. If the field is empty, the user should have permission for any Private Talk Path that it validly registers with the XRT 9000. If any Private Talk Path ID is entered, then all Private Talk path IDs not configured into this field will be disallowed!

MOTOTRBO Radio Programming

In this article we will focus on the radio settings critical for communication between the radio and SmartPTT Dispatcher. Other information on MOTOTRBO radio programming for the Connect Plus environment can be found in MOTOTRBO documentation (MOTOTRBO Connect Plus Multi-Site Digital Trunking System Planner).

As was stated before, radio programming for the Connect Plus environment requires special software: MOTOTRBO Connect Plus Option Board CPS.

To allow radio subscribers to send messages to the dispatcher, add special contact of the **Dispatch Call** type:



Note: Remember to add contacts of **Dispatch Call** for all dispatchers (if you have more than one) and specify their unique IDs, which are specified in SmartPTT Radioserver Configurator under **Profiles**.

1.5.2 SmartPTT Radioserver Configuration

The configuration process includes the following steps:

1. Run SmartPTT Radioserver Configurator, which you have downloaded and installed, as described in [SmartPTT Software Installation](#).
2. Make sure you have the necessary licenses to work in Connect Plus network, i.e., Connect Plus Voice Support and Connect Plus Data Support.

The screenshot shows the 'Settings' window with a tree view on the left and a main panel on the right. The tree view includes 'Radio Server', 'Radio Network Services', 'Add-on Modules', 'Licenses', 'Tallysman', 'Indoor Tracking', 'Event Log', 'Telephone Interconnect', 'Bridging', 'Voice Notifications', 'Web Application', 'Monitoring', 'SNMP Service', 'Control Stations', 'Connect Plus', 'Radio Activity Networks', 'NAI Networks', 'SmartPTT Radioservers', 'Profiles', 'Subscriber Groups', 'MultiGroups', and 'Metadata'. The 'Available Licenses' section on the right is titled 'SmartPTT Demo' and displays the following information:

Update Subscription Expiration Date: 12/31/2014
License Key ID: 76536CD3


License	Amount	Date
Indoor Tracking	1	12/31/2014
Connect Plus Voice Support	1	12/31/2014
Connect Plus Data Support	1	12/31/2014
NAI Voice for IP Site Connect	5	12/31/2014
NAI Voice for Capacity Plus	5	12/31/2014
NAI Voice for Linked Capacity Plus	5	12/31/2014
GPS Positioning	1	12/31/2014

Below the table is an 'Install Licenses' button. Underneath is an 'Activation' section with a 'Hardware ID' label and a text input field, followed by a 'Collect' button.

3. In the setting tree on the left, right-click **Connect Plus**, select **Add**, and then **Connect Plus**.




At that, the **Connect Plus** window opens.




4. Set parameters:

- Select **Active** to enable the Connect Plus network.
- In the **Name** field enter the name of the network.
- In the **Network ID** field enter the unique ID of the Connect Plus network, which is used inside SmartPTT. This is important if you have more than one Connect Plus network. In our case there is only one network, so we leave the default value. Note that this ID is different from the Network ID defined in the XRC Controller codeplug.
- In the **Peer ID** field enter unique ID of the virtual repeater (i.e., radioserver in Connect Plus network). This parameter is used only for voice packets to the XRT Gateway, so leave the default value. Make sure this ID is different from the repeater ID in the Connect Plus network.
- In the **Radio ID** field specify the ID of the virtual control station by default, the parameter is used to represent radioserver inside Connect Plus network, therefore, this ID will be used for the dispatcher. It is used for data and voice transmission. Make sure it is not duplicated to any of the radio ID in the system.
- In the **Interface** field specify the IP address of the virtual repeater (i.e., SmartPTT Radioserver).
- In the **UDP Start Port** specify the first local UDP port available for XRT Gateway talk paths. Each talk path requires one local UDP port. Next talk path will use **UDP Start Port** incremented by 1, and so on.

Note: If you have more than one dispatcher in the system, you should specify the unique ID for all dispatchers. To do it, create a profile per dispatcher and specify the unique ID:



5. There are three sites in our network, and each contains one XRC Controller. It is not necessary to add all the three XRC Controllers in SmartPTT Radioserver Configurator. It is required only for monitoring purposes. If you do not want to monitor all XRC Controllers, you can add only one. To add an XRC Controller, right-click **XRC Controller** and select **Add**:



6. Specify parameters for the XRC Controller:

The screenshot displays the configuration window for an XRC Controller. On the left, a tree view shows the hierarchy: Radio Server > Connect Plus > Connect Plus 1 > XRC Controllers > XRC Controller. The right pane is titled 'XRC Controller' and contains the following settings:

- Active
- Name: XRC Controller Site1
- Controller Address: 192.168.7.23
- PN, TMS, GPS
 - PN: Controller Port 4005, Local Port 50005
 - TMS: Controller Port 4007, Local Port 50007
 - GPS: Controller Port 4001, Local Port 50001
- Monitoring: Controller Port 38000, Local Port 38000, Use NAT

- Select **Active** to enable XRC Controller support.
- In the **Name** field enter the XRC Controller name. This is used only in SmartPTT Radioserver Configurator.
- In the **Controller Address** field specify the IP address of the XRC Controller. Port is not required in this field.
- Select the **PN, TMS, GPS** check box to enable data services. Specify **Controller port** and **Local port** for each service, where **Controller port** is the XRC Controller port and **Local port** is the virtual repeater port. You can leave default values. Local PN, TMS and GPS ports should not be in conflict with other local ports used for other purposes used on this PC.

Note: The PN, TMS and GPS services can be set only for one of the XRC Controllers in the network. These settings will be used by other controllers available in the network.


Note: The GPS and TMS ports specified in SmartPTT Radioserver Configurator should match the same ports in MOTOTRBO Connect Plus XRC Configuration Tool. The PN port must match the PN port in MOTOTRBO Connect Plus XRC Configuration Tool.

- Select **Monitoring** check box to be able to review the XRC Controller on the **Monitoring** panel in SmartPTT Dispatcher. Specify **Controller port** and **Local port**. The **Monitoring** service is enabled on all existing XRC Controllers. You can leave default values. If the XRC Controller is in one local network with the radioserver, leave **Use NAT** unchecked. If the XRC Controller is outside the local network of the radioserver, select **Use NAT**.


Note: Make sure that you have the general **Monitoring** service enabled (SmartPTT Radioserver Configurator > **Add-on Modules** > **Monitoring**).

7. If needed for monitoring purposes, set parameters for the other two XRC Controllers, but remember to leave the **PN, TMS, GPS** check box unchecked.

8. Add an XRT Gateway by right-clicking on **XRT Gateways** and selecting **Add**.




At that, the **XRT Gateway** window opens:



9. Specify parameters of the XRT Gateway.

- Select **Active** to enable XRT Gateway support.
- In the **Name** field enter the XRT Gateway name, which is used only in SmartPTT Radioserver Configurator.
- In the **Gateway Address:Port** field enter the IP address and port of the XRT Gateway.
- In the **Pool IDs** field use default values. The values must correspond to the range of IDs set in the XRT Gateway settings (**Pool ID**).
- **Username** and **Password** – used for authentication with the XRT Gateway and must equal XRT Gateway Username and password set up in MOTOTRBO Connect Plus XRT Configuration Tool.


10. Add talk paths on the **Talk Paths** window. They are necessary for voice communication. For each talkgroup add one talk path, select **Group** in the **Type** column, and specify the **ID**. For the dispatcher add another talk path, select **Private** in the **Type** column, and enter the **Radio ID** specified in step 4. Make sure these IDs match the IDs set in MOTOTRBO Connect Plus XRT Configuration Tool (field **Group ID** and **Console User ID**).



If required, you can define encryption settings for outgoing and incoming traffic under **Security Settings**.

1.6 Linked Capacity Plus

As was stated in the introduction, we are going to configure Linked Capacity Plus (LCP) system consisting of 3 sites with 2 repeaters on each site, see the following network scheme:




Each radio ID, either subscriber radio ID or repeater ID should be unique in the radio system. In this example you can see 2 repeaters with ID's 11 and 12 on Site 1, 2 repeaters with ID's 21 and 22 on Site 2, and 2 repeaters with

ID's 31 and 32 on Site 3. The repeater with ID=31 is a Master.


1.6.1 MOTOTRBO Equipment Programming

To program MOTOTRBO equipment you will need MOTOTRBO Customer Programming Software (CPS).

1. Connect your device to the PC via a programming cable and launch MOTOTRBO CPS.
2. Switch on the device and check its settings by clicking the **Read** button on the menu bar.



3. In the **View** menu select **Expert** to gain access to all the setting parameters.




4. In the **Device Information** tab make sure that firmware version is no older than:

- R01.12.11 or R02.30.10 for mobile or portable radios;
- R02.30.12 for repeaters.

Otherwise, contact the supplier to request firmware upgrade.

Note: It is recommended to use the same or compatible firmware versions for all MOTOTRBO equipment on

the same network.




5. To apply the changes in the settings, click **Write**.

MOTOTRBO Repeater Programming

Note: Only repeaters with 32 MB of internal memory (e.g., DR 3000 or MTR3000) can support the LCP configuration. Also, make sure that the repeater supports such features as **Network Application Interface Voice**, **Network Application Interface Data** and **Capacity Plus (Linked)**.

First of all, configure the Master repeater parameters. Each LCP system needs one repeater to act as a Master. The Master repeater has a static IP address, while other repeaters can have either static or dynamic IP addresses. All the repeaters in the LCP configuration register with the Master using the static IP address of the Master.

1. In the **General Settings** tab specify **Radio ID** and **Site ID**. In our case **Radio ID=31** and **Site ID=3**.



The screenshot shows the 'General Settings' configuration page for a radio. The page has a blue header with the title 'General Settings' and three navigation links: 'Top', 'CWID', and 'Microphone'. The configuration fields are as follows:


- Radio Name: Master
- Radio ID: 31 (highlighted with a red box)
- Site ID: 3 (highlighted with a red box)
- Site Alias: Site3
- SIT (ms): 5000
- Group Call Hang Time (ms): 3000
- Private Call Hang Time (ms): 4000
- Emergency Call Hang Time (ms): 4000

2. Add parameters in the **Network** tab.

- In the **Link Type** field select *Master*.
- In the **Master IP** and **Master UDP Port** specify the IP address and port number of the Master repeater.
- Do not select **DHCP**. Master IP address should be static.
- In the **Ethernet IP** field specify the IP address of the Master repeater, the same as in the **Master IP** field.
- In the **Gateway IP** field specify the gateway IP address for the repeater.
- In the **Gateway Netmask** field specify the gateway netmask address for the repeater.

- In the **UDP Port** field specify the UDP port of the repeater. The default value is set to *50000*.

3. In the same **Network** tab specify **Rest Channel/Site IP** and **Rest Channel/Site UDP Port**.



Rest Channel/Site IP is a virtual IP address that is required for correct operation of the LCP system. As the Rest Channel rotates through the channel pool of a site, this virtual IP address is associated with a different physical repeater only for the duration for which one of its slots is the Rest Channel. This IP address must be the same for all repeaters at the same site. **Rest Channel/Site IP** address should be at the same sub network as all repeaters of this site. No other device should use this IP address.

In the LCP system **Rest Channel/Site UDP Port** allows the user to configure the UDP port of site for communication with other sites connected within the LCP system.

4. In the **Sites** tab set up the site map. In this example we have 3 sites (see the network scheme above). *Site 1* has only one neighbor – *Site2*. *Site 2* has 2 neighbors – *Site 1* and *Site 3*. And *Site 3* has only one neighbor – *Site 2*.

Site ID	Reserved Wide Area Channels	Neighbor 1	Neighbor 2	Neighbor 3	Neighbor 4
1	0	2	None	None	None
2	0	1	3	None	None
3	0	2	None	None	None

In the **Reserved Wide Area Channels** column you can specify how many channels are to be reserved for a wide group call per site, if necessary.

5. In the **Talkgroups** tab, specify wide groups and sites on which these groups are available. You do not need to add local groups which are available only on one site.


Call ID	Site 1	Site 2	Site 3
1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
2	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>

In our example we have only two wide groups. Group 1 is a wide group which is available on all sites. So when a subscriber initiates a call to Group 1, this call will be transmitted on all sites. Group 2 is also a wide group and is available on *Site 2* and *Site 3*.

6. Set up channels. Click on **Channels**, right-click on **Zone**, select **Add** and then **Capacity Plus Voice Channel (Linked)** or **Capacity Plus Data Channel (Linked)**. Please remember that both repeater channels will be used for one and the same purpose. In LCP, a Data Revert Channel can be configured either as a local Data

Revert Channel, or as a wide area Data Revert Channel. In our configuration all repeaters will be used for voice, that is why in the Master repeater settings we add **Capacity Plus Voice Channel (Linked)**.

7. Specify **Color Code** and **Slot Channel ID**.




The color code is used to identify radio systems. Therefore, different color codes are used to identify different systems. Channels may have the same or different color codes. However, a repeater can only have one color code. Radios will ignore any channel activity not containing the matching color code for the system. Repeaters using the same frequency can be associated with different color codes.

Slot 2 Channel ID is set up automatically.

Now, configure parameters of one of the peer repeaters on *Site 1*.

1. In the **General Settings** tab specify **Radio ID** and **Site ID**. In our case **Radio ID=11** and **Site ID=1**.



General Settings

[Top](#) [CUID](#) [Microphone](#)

Radio Name

Radio ID

Site ID

Site Alias

SIT (ms)

Group Call Hang Time (ms)


Private Call Hang Time (ms)

Emergency Call Hang Time (ms)

2. In the **Network** tab configure network settings.


- In the **Link Type** field select *Peer*.
- In the **Master IP** and **Master UDP Port** specify the IP address and port number of the Master repeater.
- Do not select **DHCP**.
- In the **Ethernet IP** field specify the IP address of the repeater. Master IP address (*Site 3*) and Peer repeater IP address (*Site 1*) will be in different sub networks, because each site should be located in different sub network.
- In the **Gateway IP** field specify the gateway IP address for the repeater.
- In the **Gateway Netmask** field specify the gateway netmask address for the repeater.
- In the **UDP Port** field specify the UDP port of the repeater. The default value is set to *50000*.

3. In the same **Network** tab specify **Rest Channel/Site IP** and **Rest Channel/Site UDP Port**.



Rest Channel/Site IP is configured in each repeater. Repeaters from the same site will have the same **Rest Channel IP** address.

4. Add channels. Click on **Channels**, right-click on **Zone**, select **Add** and then **Capacity Plus Voice Channel (Linked)**. Specify **Color Code** and **Slot Channel ID** for each channel.



The **Color Code** must match the color code set for other repeaters.

When configuring a new site, you need to start numeration with **Slot 1 Channel ID=1**.

Example:

Site 3 (with Master): 1-2-Master ID=31, 3-4-Peer ID=32,

Site 1: 1-2-Peer ID=11, 3-4-Peer ID=12,


Site 2: 1-2-Peer ID=21, 3-4-Peer ID=22.

Other peer repeaters are configured likewise. When configuring, please keep in mind that:

- All repeaters from the same site should be in the same LAN.
- Each repeater must have **Master IP Address/Port** and **Rest Channel/Port**.

MOTOTRBO Radio Programming

1. In the **General Settings** specify **Radio ID**.



Select **GPS**, if you need to track the subscriber location (only for radios with GPS support DP/DM 3401, 3601, 4401, 4601, DP 4801, SL4010).

Select **Private Calls**, if radio subscriber needs to transmit private calls. If **Private Call** is not selected, radio subscriber won't be able to initiate a private call, but the user can continue to receive and respond to private calls, and is still able to initiate call alerts.

2. In the **Network** tab configure the necessary settings.

The screenshot shows the configuration page for a DP 3601 device. On the left is a navigation menu with categories like General Settings, Accessories, Buttons, Text Messages, Telemetry, Menu, Security, Network, Signaling Systems, Contacts, RX Group Lists, Channels, Scan, Roam, and Capacity Plus. The 'Network' tab is selected. The main content area has a blue header 'Network' and sub-tabs for 'Top', 'Radio Network', 'Services', and 'IP Site Connect'. Under 'Radio Network', there are fields for Radio IP (192.168.10.1), Accessory IP (192.168.10.2), and Netmask (255.255.255.0). Below this is a 'Radio Network' section with fields for CAI Network (12), CAI Group Network (225), Max TX PDU Size (500), and Telemetry UDP Port (4008). A 'Forward to PC' dropdown menu is set to 'Disabled' and is highlighted with a red box. The 'Services' section contains fields for ARS Radio ID (1), ARS IP (13.0.0.1), ARS UDP Port (4005), TMS Radio ID (1), and TMS IP (0.0.0.0). The ARS Radio ID, ARS IP, ARS UDP Port, TMS Radio ID, and TMS IP fields are also highlighted with a red box.


- In the **Forward to PC** field select *Disabled*.
- If you plan to work with SmartPTT application specify **ARS Radio ID** and **TMS Radio ID**. Remember that the **ARS Radio ID** and **TMS Radio ID** should match the **MNIS Radio ID** in the MOTOTRBO MNIS application and Slot ID in SmartPTT Radioserver Configurator. In our case, **ARS Radio ID=TMS Radio ID=Slot ID=MNIS ID=1**.

3. In the **Contacts** tab right-click on the **Capacity Plus** system to add necessary contacts (**Private Call, Group Call, All Call**) to subscriber's contact list. When configuring the Master repeater, we added 2 groups as wide groups in the **Talkgroups** tab. Group 1 with ID=1 is available for all sites, Group 2 with ID=2 is available for *Site 2* and *Site 3*. Local groups should be added in the radio settings. In this example we will add 4 groups: Group 1, Group 2 – as wide groups, Group 3 and Group 4 as local groups, and other necessary contacts.


Contact Name	Call ID	Call Receive Tone	Ring Style	Text Message Alert Tone
Group1	1	<input type="checkbox"/>	No Style	Repetitive
Group2	2	<input type="checkbox"/>	No Style	Repetitive
AllCall	255	<input checked="" type="checkbox"/>	No Style	Repetitive
Dispatcher_Voice	1	<input type="checkbox"/>	No Style	Momentary
70	70	<input checked="" type="checkbox"/>	No Style	Momentary
Group3	3	<input type="checkbox"/>	No Style	Repetitive
Group4	4	<input type="checkbox"/>	No Style	Repetitive
Dispatcher-Data	1	<input type="checkbox"/>	No Style	Repetitive

Also, add **Dispatcher Call** for transmitting data to SmartPTT Radioserver and **PC Call** to be able to initiate calls to SmartPTT Dispatcher. Make sure that the **IDs** of these calls equal **Slot ID** in SmartPTT Radioserver Configurator (see [SmartPTT Radioserver configuration](#)).


4. Add these groups to the **RX List**. In our example we use the same RX list for all sites. That is why the **RX List** contains all the groups.



5. Add all repeaters, which are in the LCP system, to the **Channel Pool**. The color code should equal the color code specified for repeaters. In our case **Color Code=1**. Define the RX and TX frequencies. They must correspond to the frequencies set in the repeater, but RX of the radio must correspond to TX of the repeater and TX of the radio must correspond to RX of the repeater.




6. Create **Voice** lists and **Data** lists according to the amount of sites. As all of our repeaters are Trunk repeaters (transmit voice and data), create only **Voice** lists. When adding new **Voice** list, under the **Available** list you can see all the channels which were added to the **Channel Pool**. So, for *Site 1* add a **Voice** list (LCP Site 1) and add *LCP Site 1-11* and *LCP Site 1-12* to this list.



Please note that **IDs** in the **Members** list should correspond to **Slot 1 ID Channel** and **Slot 2 ID Channel** specified in repeater settings.

7. Create **Voice** lists for *Site 2* and *Site 3* accordingly.

8. Configure **Sites** lists. If you do not use roaming, create several site lists and add only one site per list.




Since in this example there are three Sites, add three **Sites** lists.

For each **Site** configure:

- **Site ID** – ID of the site to which the subscriber radio is connected.
- **Site Alias** – name of the site to which the subscriber radio is connected.
- **Voice List** – Voice Channel List which the subscriber radio will use to make voice calls when on the site.
- **Data List** – Data Channel List which the subscriber radio will use to make data calls when on the site.
- **RX Group List** – RX Group List which the subscriber radio will use to receive group calls when on the site.

If subscriber roams between different sites, one site list will contain several sites.

In our case a subscriber with **Radio ID=100** can roam between all three sites, so we created one **Sites** list with all the sites.



LCP Sites

RSSI Threshold (dBm)

	Site ID	Site Alias	Voice List	Data List	RX Group List
▶	1	Site1	LCP Site1	None	LCPVoice
	2	Site2	LCP Site2	None	LCPVoice
	3	Site3	LCP Site3	None	LCPVoice

9. Add LCP Personalities. To do this, right-click on **Zone** and add **Capacity Plus Personality (linked)**.

The screenshot shows the configuration page for 'LCP Site1'. On the left is a navigation tree with categories like General Settings, Accessories, Buttons, Text Messages, Telemetry, Menu, Security, Network, Signaling Systems, Contacts, RX Group Lists, Channels, Zone1 (containing LCP Site1, LCP Site2, LCP Site3), Channel Pool, Zone2, Scan, Roam, and Capacity Plus. The main area is titled 'LCP Site1' and has tabs for 'Top', 'RX', and 'TX'. Under 'RX', there are checkboxes for 'Emergency Alarm Indication' (checked), 'Emergency Alarm Ack' (unchecked), and 'Emergency Call Indication' (checked). Under 'TX', there are various settings: 'Contact Name' (Group1), 'Emergency System' (Sys1), 'VOX' (unchecked), 'Power Level' (Low), 'TOT (sec)' (60), 'TOT Rekey Delay (sec)' (0), 'Allow Interruption' (unchecked), 'TX Interruptible Frequencies' (unchecked), 'Admit Criteria' (Channel Free), 'In Call Criteria' (TX Interrupt), 'RSSI Threshold (dBm)' (-90), 'Private Call Confirmed' (checked), and 'Data Call Confirmed' (unchecked). Other settings include 'ARS' (On System/Site Change), 'Privacy' (unchecked), 'Privacy Alias' (Privacy Key1), 'RAS Alias' (None), 'Option Board' (unchecked), 'Lone Worker' (unchecked), 'Messaging Delay (ms)' (60), 'Compressed UDP Data Header' (unchecked), 'Auto Roam' (checked), 'Site List' (LCP Sites), 'Rest Channel Acquisition TOT (min)' (5), 'Beacon Interval (ms)' (1920), and 'RX Only' (unchecked).

For each channel specify:

- **ARS** – select *On System/Site Change*. ARS feature provides an automatic radio registration. When the radio powers up, the radio automatically registers with the server. This feature is also used with Text Messaging or Location Services.
- **Auto Roam** – select **Auto Roam** if the radio is to roam between sites in the LCP system. If disabled, the

radio subscriber won't be able to roam to another LCP site when moving from one site to another.

- For each channel select appropriate **Sites** list. The subscriber radio can roam to the sites listed in the **Sites** list.
- Select **Contact Name** which defines the call that may be initiated on the channel by pressing the PTT button, when there are no active calls on the channel.
- Select **Private Call Confirmed** and clear **Data Call Confirmed**.

1.6.2 SmartPTT Radioserver Configuration

1. Run SmartPTT Radioserver Configurator, which you have downloaded and installed, as described in [SmartPTT Software Installation](#).
2. In the setting tree on the left, right-click on **NAI Systems**, point to **Add** and click **NAI - Linked Capacity Plus**.
3. In the opened window specify the following settings of the future LCP network.

The screenshot displays the configuration interface for a radio server. On the left is a tree view of the configuration hierarchy, with 'NAI - Linked Capacity Plus 1' selected under 'NAI Systems'. The main window on the right is titled 'NAI - Linked Capacity Plus Network' and contains the following settings:

- Active
- Name: NAI- Linked Capacity Plus 1
- Network ID: 1
- Peer ID: 1
- Interface: 192.168.37.13 Port: 50000
- Master repeater address (host:port): 10.150.0.20:50000 [Test]
- Authentication key: [Empty field]
- Voice transmission: Repeaters
- Group call hang time, ms: 3000
- Private call hang time, ms: 4000
- Max number of telephone calls: 100
- Data transmission
- Monitoring

- **Name** – add network name.
- **Network ID** – specify unique ID of the network. The network ID must not match any ID of the other SmartPTT Radioserver networks.
- **Peer ID** – enter unique ID of the virtual repeater in the network. The virtual repeater ID must not match any of the other repeater IDs in this network.
- **Interface** – specify the IP address of the PC where SmartPTT Radioserver is installed.
- **Port** – set up port number of SmartPTT Radioserver. It should differ from the corresponding ports in other networks.
- **Master repeater address (host:port)** – specify IP address and port number of the Master repeater (see **Master IP** and **Master UDP Port** in MOTOTRBO CPS). In this example it is *10.150.0.20:50000*.
- Click **Test** to check connection between the virtual and Master repeaters.
- **Authentication Key** – enter repeater authorization key (to be equal to the **Authentication Key** in the repeater settings in MOTOTRBO CPS). In this example we are not setting any authentication keys.
- **Voice transmission** can be carried out in two ways: via repeaters and via control stations. To transmit voice via control stations, configure control station parameters and profiles for making private calls. To transmit voice via repeaters, configure virtual control station channels and talkgroups of the channel. The number of channels depends on the network type. To ensure data packets transmission over the network, configure the DDMS and MNIS services. To transmit CSBK commands use control stations for voice transfer. To transmit data and monitoring data select the corresponding check boxes (**Data transmission** and **Monitoring**). If **Data transmission** is not selected, all data packets will be gray and no data type differentiation will be applied in the **Monitoring** panel in SmartPTT Dispatcher. If **Data transmission** is selected, the data packets addressed to you will be defined, and other data packets, not addressed to you, will be gray.

4. Configure slot parameters. In order to do that, go to **Slot 1** in the setting tree of SmartPTT Radioserver Configurator.


The screenshot displays the configuration interface for a radio server. On the left, a tree view shows the hierarchy: Radio Server > NAI-Linked Capacity Plus 1 > Slot 1. The right pane, titled 'NAI Control Station', contains the following settings:

- Active
- Name: Slot 1
- Radio ID: 1
- CAI Network: 12
- CAI Network for Groups: 225
- Allow Telephone Interconnect
- TX Time-Out Timer, s: 60
- Options:
 - Emergency Alarm Confirmed
 - Allow Transmit Interrupt
 - GPS Transmission Mode: Data
- Confirmed events:
 - Private Call Confirmed

- **Name** – specify the name of the slot.
- **Radio ID** – set unique ID of a virtual control station corresponding to the network slot. Remember that it should match **ARS Radio ID**, **TMS Radio ID** and **MNIS ID**, in this example it is *1*.
- **CAI Network** – CAI-network ID. Use the default value of 12 (must match MOTOTRBO CPS settings).
- **CAI Network for Groups** – CAI-network for groups ID. Use the default value of 225 (must match **CAI Group Network** in MOTOTRBO CPS settings).
- **Emergency Alarm Confirmation** – select this check box if you need the emergency alarm be acknowledged.
- **Private Call Confirmed** – select this check box if you need set private calls on the current digital channel as confirmed.
- **Allow Transmit Interrupt** – select this check box if you need the ability to interrupt a radio subscriber.
- **GPS Transmission Mode** – allows you to select the way how to transmit location updates: as a data packet in multiple bursts or as a single CSBK (Control Signaling Block). This time select **Data**.
- **Allow Telephone Interconnect** – select this check box if you need the ability to make telephone calls

on the slot.

- Configure talkgroup parameters. To do that, click **Talkgroups**. Parameters of wide area and local groups are set in the **Control Station Talkgroups** window. In order to display wide area talkgroups by the SmartPTT Dispatcher application, add necessary talkgroups in SmartPTT Radioserver Configurator, define group identifiers which correspond to the identifiers of the wide area groups in the repeater MOTOTRBO CPS settings and select *Wide* in the **Site Number** field. In this example we have two wide area talkgroups and two local talkgroups, so we add them into SmartPTT Radioserver Configurator.




Talkgroups not specified in the repeater settings are regarded as local groups. Local group call does not go beyond the site on which the call was initiated.


To add local talkgroups, just add them in SmartPTT Radioserver Configurator, define their identifiers and select site number from the list in the **Site Number** field.

Note: Wide area and local talkgroup identifiers must differ.


- Configure MNIS and DDMS settings for data transmission under **MNIS Settings** and **DDMS Settings**.



- 1) Under **MNIS settings** select *Local Socket* in the **Socket Type** field since the MOTOTRBO Network Interface Service Configuration Utility application is installed on the same PC as SmartPTT Radioserver.
- 2) **MNIS Control Interface** – use *localhost*, if MOTOTRBO Network Interface Service is installed on the same PC as the radioserver. If MOTOTRBO Network Interface Service and the radioserver are installed on different PCs, use the interface specified in the **MNIS Relay Address** field. The port should match the port number specified in the **MNIS Control Interface TCP Port** field in MOTOTRBO Network Interface Service Configuration Utility settings:






- 3) In the **Interface** field select the IP address of the PC where MOTOTRBO Network Interface Service is installed. It must match the IP address specified in the **Tunnel IP Address** field of MOTOTRBO Network Interface Service Configuration Utility.
- 4) In the **MNIS ID** field set up the Common Air Interface (CAI) ID of the MNIS in the radio network. The ID is used by other calling radios when addressing MOTOTRBO Network Interface Service. Make sure **MNIS ID** matches the **MNIS Application ID** field in the **General** tab in MOTOTRBO Network Interface Service Configuration Utility. It is also recommended that **MNIS ID** should match **Radio ID** in the radioserver slot settings.



5) In the **TMS Port**, **Telemetry Port** and **Location Port** fields specify ports where the radioserver will expect text messages, telemetry and GPS data. The ports should match the ports set in the **TMS UDP PORT**, **Telemetry UDP Port**, **Location Server UDP Port** fields in MOTOTRBO Network Interface Service Configuration Utility (**Advanced > Network**).

6) Under **DDMS settings** specify **Server Address**, i.e., IP address of the PC with the MOTOTRBO DDMS Administrative Client application installed, and port number of the DDMS server. In this case the DDMS server is installed on the same PC as the radioserver. The port number in this field must match the port number in the **PortWatcher** field of the MOTOTRBO DDMS Administrative Client (**Interfaces > Watcher Settings**).



7. Save changes by clicking **Save** . To cancel the changes made, click the **Restore** button . All the changes, made after the last save, will be restored. To apply the saved changes you must restart the service.

The service is managed using the following buttons: Start , Stop and Restart .

1.6.3 MNIS and DDMS Client Configuration


In order to process data packets, ARS, Call Alerts, GPS, TMS, it is obligatory to have MOTOTRBO Network

Interface Service Configuration Utility (MNIS) and MOTOTRBO DDMS Administrative Client properly installed and configured.


Let's start with MOTOTRBO Network Interface Service Configuration Utility (MNIS).

Note: Before configuring, make sure the firmware versions of the repeaters and MOTOTRBO Network Interface Service are compatible (please find compatibility information in MNIS Release Notes).


1. In the **General** section in the **System Operation Mode** field select network type. In our case, it is *Linked Capacity Plus*.



2. In the **Linked Capacity Plus** section set up **Master IP Address** and **Master UDP Port** fields. These values should correspond to the same values in MOTOTRBO CPS and in SmartPTT Radioserver Configurator, which you will set up later.



3. It is recommended to clear the **Data Call Confirmed** field in the **Advanced** section and to specify the identifier in the **MNIS LE ID** field explicitly. Make sure **MNIS LE ID** does not match **Peer ID** of any repeaters in the system.




Note: In the Firewall settings add MNIS into the exception list.

DDMS operation is closely connected to MNIS for data exchange (MNIS serves as DDMS Watcher). DDMS filters ARS packets, received by the repeater, and information on the radio presence in the network is sent to all systems for further processing.

Therefore, when you configure DDMS settings, make sure that:

1. The **PortWatcher** field in MOTOTRBO DDMS Administrative Client matches the **WatcherPort** field in MNIS settings (**Advanced > Network**).



2. The **PORT SU** field (**Interfaces > ARS Settings**) in MOTOTRBO DDMS Administrative Client matches the **ARS UDP Port** field in MOTOTRBO Network Interface Service Configuration Utility (**Advanced > Networks**).

